



Figure 12.3 A surface irrigation system left coiled on top of treatment tank

Solution

- Discard the supplied pipe and sprinklers.
- Install a number of fixed distribution lines (suitable for burial) with sprinklers that comply with council's approval to evenly distribute effluent across the allocated area.
- Place pop-up sprinklers at one every 12 square metres to ensure even sprinkler coverage.
- Install a sequencing valve to ensure effluent is evenly irrigated throughout each field.